

USB_DN
USB_DP
HDD_34
HDD_12
FAN_PWM
FAN_TACHO
NET_IN
HDD_IN
LED2_BLUE
LED3_RED
LED4_BLUE
LED4_RED
LED1_BLUE
LED1_RED
LED_BUP_BLUE
LED_BUP_RED
LED3_BLUE
LED2_RED
PWM_BLAU
PWM_ROT
LED_PWR_BLUE
LED_PWR_RED
LED_NET_BLUE
LED_NET_RED
LED_INF_BLUE
LED_INF_RED
LED_DSK_BLUE
LED_DSK_RED
USB_DN
USB_DP
IC1
51JM128-LQFP64
LQFP64
RESET
BKGD/MS
IRQ/TPMCLK
PTA5/RGPIO5
PTA4/RGPIO4
PTA3/RGPIO3
PTA2/RGPIO2
PTA1/RGPIO1
PTA0/RGPIO0
PTB7/ADP7
PTB6/ADP6
PTB5/KBIP5/ADP5
PTB4/KBIP4/ADP4
PTB3/SS2/ADP3
PTB2/SPSCK2/ADP2
PTB1/MOSI2/ADP1
PTB0/MISO2/ADP0
PTC6/RXCAN
PTC5/RXD2
PTC4
PTC3/TXD2
PTC2/IRO
PTC1/SDA1
PTC0/SCL1
PTD5/EXTAL
PTD4/XTAL
PTD3/KBIP7
PTD2/KBIP6
PTD1/KBIP1
PTD0/KBIP0
VREFH
VREFL
VDDAD
VDD_1
PTD7
PTD6
PTD5
PTD4/ADP11
PTD3/KBIP3/ADP10
PTD2/KBIP2/ACMP0
PTD1/ACMP-/ADP9
PTD0/ACMP+/ADP8
PTE7/SS1
PTE6/SPSCK1
PTE5/MOSI1
PTE4/MISO1
PTE3/TPM1CH1
PTE2/TPM1CH0
PTE1/RXD1
PTE0/TXD1
PTF7/TXCAN
PTF6
PTF5/TPM2CH1
PTF4/TPM2CH0
PTF3/TPM1CH5
PTF2/TPM1CH4
PTF1/TPM1CH3
PTF0/TPM1CH2
USBDN
USBDP
VUSB33
VSSAD
VSS_1
VSS_2
IRF7104PbF
SM
GND